DYNEX™

DX-WRM1402
Retractable Wired USB Mouse



Before using your new product, please read these instructions to prevent any damage.

Package contents

- Retractable Wired USB Mouse
- *Quick Setup Guide*

System requirements

- Windows® 8, Windows® 7, Windows Vista®, or Windows® XP
- One available USB port

Setting up your mouse

1 Turn the mouse over and hold it in one hand, pull out the USB cord and adjust to your desired length.



2 Plug your mouse into an available USB port on your computer. The computer automatically detects the mouse.

Caution: If your desk top is red in color, transparent, or highly reflective it may interfere with the optical sensor of the mouse. We suggest that you use a mouse pad or use the mouse on a different surface.

To retract the USB cord

- Slightly pull out the USB cord and the embedded reel will rewind the cord automatically.



Cleaning your mouse

- Wipe the mouse with a damp, lint-free cloth.

Troubleshooting

- Make sure that your computer meets the system requirements.
- Only use the mouse on a clean, flat, non-slippery surface to ensure smooth and accurate cursor action.

Legal notices

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

IC Statement

This Class B digital apparatus complies with Canadian ICES-003

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

One-year limited warranty

For complete warranty, visit www.dynexproducts.com.

Contact Dynex

For customer service call 1-800-305-2204

www.dynexproducts.com

DYNEX is a registered trademark of BBY Solutions, Inc. Registered in some countries.
Distributed by Best Buy Purchasing, LLC, 7601 Penn Ave South, Richfield, MN 55423 U.S.A.
©2013 BBY Solutions, Inc. All Rights Reserved.